



This section describes how to register an SMB folder.

1. Press the **[User Tools/Counter]** key.



2. Press **[System Settings]**.



3. Press **[Administrator Tools]**.
4. Press **[Address Book Management]**.
5. Check that **[Program / Change]** is selected.
6. Select the name whose folder you want to register.  
Press the name key, or enter the registered number using the number keys.
7. Press **[Auth. Info]**, and then press **[Next]**.



- Press **[Specify Other Auth. Info]** on the right side of "Folder Authentication".  
When **[Do not Specify]** is selected, the SMB User Name and SMB Password that you have specified in "Default User Name / Password (Send)" of File Transfer settings applies.
- Press **[Change]** under "Login User Name".
- Enter the login user name of the destination computer, and then press **[OK]**.
- Press **[Change]** under "Login Password".
- Enter the password of the destination computer, and then press **[OK]**.
- Enter the password again to confirm, and then press **[OK]**.
- Press **[Folder]**.
- Check that **[SMB]** is selected.

To specify a folder, you can either enter the path manually or locate the folder by browsing the network.



- Press **[Change]** or **[Browse Network]**, and then specify the folder.  
To specify a folder, you can enter the path to it manually, or select it by browsing the network.
- Press **[Connection Test]** to check the path is set correctly.
- Press **[Exit]**.  
If the connection test fails, check the settings, and then try again.
- Press **[OK]**.
- Press **[Exit]**.
- Press the **[User Tools/Counter]** key.